



SAPPHIRE Super platinum RX580 GPU Water Block

BS-SARX580-PA



Remove the red position screw

①



Clean up and reapply GPU core thermal grease


Remove the original radiator support block in particular , Labeled red

②




In the water block floor with good thermal grease

③



Attention to red position screw for installation drawing

④



installation is complete